
SOHO HOME



Available in 4 sizes

170 x 240cm (H170 x W240 x D2cm / H5'6" x W7'10" x D0.8") 200 x 300cm (H200 x W300 x D2cm / H6'6" x W9'10" x D0.8") 270 x 360cm (H270 x W360 x D2cm / H8'10" x W11'9" x D0.8") 20 x 30cm (Swatch) (H20 x W30 x D2cm / H7" x W11" x D0.8")

Arcus Rug, 170 x 240cm

€2,600 Regular price €2,210 Member price

Our Arcus design is a nod to 1970s-era shag pile rugs. Hand-knotted by skilled artisans in India with 19 knots per square inch, it has a long New Zealand wool pile, which is warm and extremely soft underfoot, making it ideal for your first step out of bed or near the sofa. The repetitive square pattern takes influences from the architectural shapes and colour palette of Soho House Rome.

Dimensions

Dimensions: H170 x W240 x D2cm / H5'6" x W7'10" x D0.8" Weight: 14kg / 30.9lbs Packaged dimensions: H175 x W21 x D21cm / H68.9 x W8.3 x D8.3" Packaged weight: 14kg / 30.9lbs

Details

Assembly required: No Composition: 100% Cotton Handmade: Yes Pile: 100% Wool Rug style: Geometric Technique: Hand Knotted

Care instructions: Vacuum regularly on a low-power setting, using a vacuum cleaner without a beater brush, to prevent debris from settling into roots of the fibres. Shedding is a natural characterstic of the handmade rugs which reduces over a period of usage. Avoid direct and continuous exposure to sunlight. Use rug protectors under the legs of heavy furniture to avoid flattening piles. Do not pull loose ends. Clip them with scissors to remove. Turn carpet around occasionally to equalise wear. Remove spills immediately; if liquid, blot with clean, undyed cloth by pressing firmly around the spill to absorb as much as possible. For hard-to-remove stains, professional rug cleaning is recommended. Store your rug by rolling it front side out and wrapping in cloth for protection. Do not fold or store rug in an airtight plastic bag. Place in dry, well-ventilated area. with a soft, dry cloth, spot clean with mild soap if needed; occasional professional cleaning may be required. Do not dry clean. If loose end appears, do not pull; Instead clip with scissors and tie a knot at the loose ends. Avoid direct exposure to sunlight. Rotate rug occasionally to equalize wear, if the rug gets wet, place it on a flat surface to dry. Store your rug by rolling, and wrap with cloth for protection. Rug pad recommended.