


# SOHO HOME



## Jensen Runner, 75 x 250cm

~~€2,250~~ €1,700 Regular price

~~€1,913~~ €1,360 Member price



The Jensen runner is inspired by traditional 19th-century Persian rug designs found in Soho Farmhouse. An intricate all-over pattern and decorative border is met with rich and deep warm tones as the perfect grounding layer for a hallway. Hand-knotted in India from a combination of Afghan and New Zealand wool, each one takes up to six months to craft with 41 knots per square inch. Traditionally, hand-knotted rugs still form the highest quality standard among all types of rugs and, depending on the type of knot, can last for generations in the home.

### Dimensions

**Dimensions:** H75 x W250 x D2cm / H2'5" x W8'2" x D0.8"

**Weight:** 3kg / 6.6lbs

**Packaged dimensions:** H80 x W18 x D18cm / H31.5 x W7.1 x D7.1"

**Packaged weight:** 3kg / 6.6lbs

# SOHO HOME

## Details

**Assembly required:** No

**Composition:** 100% Cotton

**Handmade:** Yes

**Pile:** 100% Wool

**Rug style:** Classic

**Technique:** Hand Knotted

**Care instructions:** Vacuum regularly on a low-power setting, using a vacuum cleaner without a beater brush, to prevent debris from settling into roots of the fibres. Shedding is a natural characteristic of the handmade rugs which reduces over a period of usage. Avoid direct and continuous exposure to sunlight. Use rug protectors under the legs of heavy furniture to avoid flattening piles. Do not pull loose ends. Clip them with scissors to remove. Turn carpet around occasionally to equalise wear. Remove spills immediately; if liquid, blot with clean, undyed cloth by pressing firmly around the spill to absorb as much as possible. For hard-to-remove stains, professional rug cleaning is recommended. Store your rug by rolling it front side out and wrapping in cloth for protection. Do not fold or store rug in an airtight plastic bag. Place in dry, well-ventilated area. with a soft, dry cloth, spot clean with mild soap if needed; occasional professional cleaning may be required. Do not dry clean. If loose end appears, do not pull; Instead clip with scissors and tie a knot at the loose ends. Avoid direct exposure to sunlight. Rotate rug occasionally to equalize wear, if the rug gets wet, place it on a flat surface to dry. Store your rug by rolling, and wrap with cloth for protection. Rug pad recommended.