
SOHO HOME









Available in 4 sizes

 $170 \times 240 cm \ (H240 \times W170 \times D1 cm / H7'10" \times W5'7" \times D0.4")$ $200 \times 300 cm \ (H300 \times W200 \times D1 cm / H9'10" \times W6'7" \times D0.4")$ $270 \times 360 cm \ (H360 \times W270 \times D1 cm / H11'10" \times W8'10" \times D0.4")$ $20 \times 30 cm \ (Swatch) \ (H30 \times W20 \times D1 cm / H1'0" \times W8" \times D0.4")$

Perga Rug, 170 x 240cm

£2,495 Regular price £2,121 Member price

The folk floral design of our Perga rug has been hand-drawn in-house, before being transformed into a wool flat-pile design.

Hand-knotted in India, each of our rugs takes up to six months to craft with 64 knots per square inch. The deep navy hue perfectly complements the flowers' pops of colour to bring a traditional look into the home.

Dimensions

Dimensions: H240 x W170 x D1cm / H7'10" x W5'7" x D0.4"

Weight: 12kg / 26.5lbs

Packaged weight: 12kg / 26.5lbs

Details

Composition: Pile: 100% Wool Base: 61% Polyester, 37% Cotton, 2% Viscose Overall: 54% Wool, 28% Polyester, 17% Cotton, 1% Viscose

Construction: Hand Knotted

Care instructions: To protect your investment, use a rug pad. A rug pad provides traction between the rug and floor to prevent slipping. It adds padding and keeps the rug smooth and flat. Extending the life of the rug, a pad protects the backing and prevents any possible colour transfer. Rotate or reposition your rug and/or rug pad every 3 months. This will aid in a more uniform floor surface patina and decrease the likelihood of the rug pad or exposed backing adhering to the floor surface where they are placed. Rotating your rug will promote even wear on the surface and extend the life of the rug. Shedding is inherent to wool rugs and occurs primarily within the first 3-6 months in last of caring for your rug Vacuum regularly on a low setting. Do not use heavy duty vacuums. Blot spills Immediately with a soft , dry cloth, spot clean with mild soap if needed; occasional professional cleaning may be required. Do not dry clean. If loose end appears, do not pull; Instead clip with scissors and tie a knot at the loose ends. Avoid direct exposure to sunlight. Rotate rug occasionally to equalize wear, if the rug gets wet, place it on a flat surface to dry. Store your rug by rolling, and wrap with cloth for protection. Rug pad recommended.