
## SOHO HOME









#### Available in 4 sizes

 $170 \times 240 cm \ (H170 \times W240 \times D2 cm \ / \ H5'6" \times W7'10" \times D0.8")$   $200 \times 300 cm \ (H200 \times W300 \times D2 cm \ / \ H6'6" \times W9'10" \times D0.8")$   $270 \times 360 cm \ (H270 \times W360 \times D2 cm \ / \ H8'10" \times W11'9" \times D0.8")$   $20 \times 30 cm \ (Swatch) \ (H20 \times W30 \times D2 cm \ / \ H7" \times W11" \times D0.8")$ 

# Arcus Rug, 20 x 30cm (Swatch)

£15 Regular price £13 Member price

Our Arcus design is a nod to 1970s-era shag pile rugs. Hand-knotted by skilled artisans in India with 19 knots per square inch, it has a long New Zealand wool pile, which is warm and extremely soft underfoot, making it ideal for your first step out of bed or near the sofa. The repetitive square pattern takes influences from the architectural shapes and colour palette of Soho House Rome.

### **Dimensions**

**Dimensions:** H20 x W30 x D2cm / H7" x W11" x D0.8"

Weight: 1kg / 2.2lbs

Packaged weight: 1kg / 2.2lbs

### **Details**

Assembly required: No Composition: 100% Cotton

Handmade: Yes
Pile: 100% Wool
Rug style: Geometric
Technique: Hand Knotted

Care instructions: Vacuum regularly on a low-power setting, using a vacuum cleaner without a beater brush, to prevent debris from settling into roots of the fibres. Shedding is a natural characterstic of the handmade rugs which reduces over a period of usage. Avoid direct and continuous exposure to sunlight. Use rug protectors under the legs of heavy furniture to avoid flattening piles. Do not pull loose ends. Clip them with scissors to remove. Turn carpet around occasionally to equalise wear. Remove spills immediately; if liquid, blot with clean, undyed cloth by pressing firmly around the spill to absorb as much as possible. For hard-to-remove stains, professional rug cleaning is recommended. Store your rug by rolling it front side out and wrapping in cloth for protection. Do not fold or store rug in an airtight plastic bag. Place in dry, well-ventilated area. with a soft, dry cloth, spot clean with mild soap if needed; occasional professional cleaning may be required. Do not dry clean. If loose end appears, do not pull; Instead clip with scissors and tie a knot at the loose ends. Avoid direct exposure to sunlight. Rotate rug occasionally to equalize wear, if the rug gets wet, place it on a flat surface to dry. Store your rug by rolling, and wrap with cloth for protection. Rug pad recommended.